

BETJENINGSVEJLEDNING

TEXAS PRO•TRAC 550 TG



TEXAS Andreas Petersen A/S
Knullen 2 - 5260 Odense S
Tlf.: 63 95 55 55 Fax: 63 95 55 58
Internet adresse: www.texas.dk
E-mail adresse: post@texas.dk

BETJENINGSVEJLEDNING

Texas Pro•Trac 550 TG

Tak for Deres valg af en Texas Pro•Trac universaltraktor. Vi er sikre på at Deres nye maskine lever helt op til Deres forventninger om sikkerhed og ydeevne.

Texas arbejder konstant på en forsøgt udvikling af maskiner og tilbehør; derfor forbeholder vi os retten til at ændre maskinerne både i form, teknik og design.

SIKKERHEDSFORESKRIFTER

Før start af motoren skal denne betjeningsvejledning læses og forstås.

Personer under 18 år må ikke arbejde med maskinen.

Ved arbejde med universaltraktoren bør sikkerhedsanvisningerne følges nøje. Gennemlæs betjeningsvejledningen grundigt inden du starter din maskine. Vær sikker på at du omgående kan stoppe maskinen og slukke motoren i tilfælde af uheld. Samtlige instruktioner omkring sikkerhed og vedligeholdelse af fræseren tjener til din sikkerhed.

En Pro•Trac må ikke bruges til andet arbejde end der er beskrevet i betjeningsvejledningen.

Brug kun tilbehør og originale reservedele anbefalet af Texas. Montering af ikke godkendte dele kan medføre forøget risiko for defekt og er derfor ikke tilladt. Ethvert ansvar fraskrives ved ulykke eller anden skade som forårsages pga. montering af uoriginale dele.

Før maskinen tages i brug, bør forhandleren eller anden fagkyndig instruere bruger i korrekt brug og vedligehold af maskinen.

Den der betjener maskinen er ansvarlig for andre personer i arbejdsmiljøet. Brug aldrig maskinen når der er børn eller dyr i nærheden.

Maskinen må kun bruges af personer, som er fortrolig med betjeningen af maskinen. Betjeningsvejledningen skal under alle omstændigheder altid følge maskinen.

Universaltraktoren må kun benyttes af personer, som er udhvilede, raske og i god form. Hvis arbejdet er udmattende, bør der holdes jævnlige pauser. Efter indtagelse af alkohol må der ikke arbejdes med maskinen.

De , fra fabrikken, monterede styreheder, som f.eks. koblingskablet fra håndtaget må ikke fjernes.

ARBEJDE PÅ MASKINEN

Hvis sikkerhedsudstyret afmonteres må maskinen ikke benyttes før det er monteret igen. Ved rengøring, vedligeholdelse og montering af nedenstående emner skal motoren være afbrudt og tændrørshætten taget af tændrøret.

- Montering af tilbehør
- Vedligeholdelse af motor eller maskine
- Justeringer og reparationer
- Rengøring/fjernelse af tilstopninger
- Ved transport og oplagring af maskinen.

DAGLIG VEDLIGEHOLDELSE

Rengør dagligt motoren og gearkassen for græs, blade og olie, for at undgå brand.

Ved brug af haveslange til rengøring af maskinen må du aldrig spule direkte på motoren.

En skadet lyddæmper forårsager for meget støj og bør udskiftes.

Ved reparationer må der kun benyttes originale reservedele.

Motorens omdrejningstal er indstillet fra fabrikken. Den faste max. indstilling beskytter motoren og må derfor ikke ændres.

Efterse maskinen for defekte betjenings- og sikkerhedsmærker. Bør udskiftes hvis de er defekte.

ADVARSELSMÆRKER

"PAS PÅ ROTERENDE KNIVE"

Arbejde med maskinen på stejle områder er farligt. Benyt kun maskinen på områder, hvor den kan håndteres sikkert.

Ved arbejde med maskinen skal der benyttes tætsiddende tøj, solide arbejdshandsker samt sko/støvler med skridsikre såler.

OPSTART

Husk at tjekke motoren for olie før enhver opstart.

Hver gang maskinen benyttes skal fræseren efterses for evt. fejl og mangler. Opmærksomheden henledes især på gasgrebet, koblingshåndtaget, afbryderknappen, knivene samt for utætheder i brændstofsystemet.

Maskinen må kun startes på et plant underlag. Når maskinen starter skal brugerne stå fast og have godt greb i maskinen.

PÅFYLDNING AF BRÆNDSTOF

Vær forsiktig når der påfyldes brændstof, da det er meget brandfarligt og indeholder giftige gasarter og eksplasive stoffer.

Der må aldrig påfyldes brændstof når motoren er i gang eller er varm. Brug altid en tragt eller en dunk med hældetud når der påfyldes brændstof.

Ryg aldrig og undgå åben ild under påfyldningen.

Hvis der under påfyldningen spildes brændstof, skal det straks renses op, og maskinen opstares i god afstand fra optankningsstedet.

Vær opmærksom på at der ikke spildes brændstof på arbejdstøjen. Hvis dette skulle ske, skal tøjet straks skiftes.

Påfyld aldrig brændstof i lukkede rum !

ARBEJDSBETINGELSER

Før maskinen tages i brug skal styret indstilles til den korrekte arbejdshøjde.

Vær forsiktig ved fræsning i hård og stenet jord. Hav altid begge hænder på styret, således at arbejdet kan ske på en rolig og forsvarlig måde.

Inden fræsningen påbegyndes, bør jorden renses for store sten, metaldele eller andre faste genstande. Pas på skjulte rødder og træstubbe.

Betjen kun maskinen ved passende lysforhold. Arbejdet med maskine skal foregå roligt og velovervejet.

Check med jævne mellemrum bolte og møtrikker. Ved mærkbare rystelser bør maskinen straks stoppes og fejlsøgningen begynde.

Af sikkerhedsmæssige hensyn skal motoren altid stoppes, når man forlader den.

TEKNISKE DATA PRO•TRAC 550 R

Motortype	Powerline 5 HK	
Kobling	Tør enkelt manuel kobling	
Gearkasse	1 Gear frem og 1 gear tilbage.	
Kørehastighed ved 3600 motoromdrehninger og 13 x 5.00 - 6 hjulmontering		
Som Fræser Frem	1,4 km/t	
	Bak	2,2 km/t
Som rotorklipper	Frem	2,2 km/t
	Bak	1,4 km/t
Kraftudtag	Uafhængig fra gearkassen 646 som fræser 965 som rotorklipper.	
Hjul	13 x 5.00 - 6 luftgummi.	
Fræser	50 cm. Justerbar fra 33 cm.	
Håndtag	Justerbart i højden/side. Vendbart 180.	
Bredde	50 cm. med fræser.	

FØR START AF MOTOR

BEMÆRK - MOTOREN ER LEVERET UDEN OLIE !!!

Før start af motor skal følgende tjekkes:

- Motoren skal stå i vandret stilling. Oliepåfyldningsskruen løsnes, og olien påfyldes.
- Motoren har ikke nogen oliepinds måler med mærker på. Olien (ca. 0,7 ltr.) påfyldes til underkanten af påfyldningshullet. Er oliestanden under målepindens spids i tilskruet tilstand, påfyldes olie.
- Brug SAE 30 motorolie. Den er specielt fremstillet til brug på luftkølede motorer. Hvis denne olietype ikke kan fremskaffes, kan der bruges en mineralsk olie med en viskositet på 15w-40.
- Brug kun olie af god kvalitet som SC, SD, SE, SF og SG.
- Alle bolte og møtrikker. Især dem der holder tilbehøret.
- At gearstang og PTO er i neutral.
- At luftfiltret ikke er stoppet, tørfilter, og at der er olie på oliebadsfiltret.
- Oliehøjden i gearkassen (0,75 l.)
- Påfyld ny frisk, blyfri benzin, alle oktantal kan benyttes, eller diesel.
- Ved påfyldning af brandstof skal maskinen stå vandret. Gammel brændstof skal altid udskiftes.

START AF MOTOR

Tilslut motorstoppet, ved at trække koblingshåndtaget og låse det i aktiveret position (fig. 3) Åbn for benzinhansen - tryk gashåndtaget halvt i bund, og hvis motoren er kold, aktiver chokeren, som sidder på karburatoren.

Start motoren med et hurtigt træk i startsnoren. Når motoren er startet skubbes choker armen langsomt tilbage, mens motoren varmer op. Vent 2 - 3 minutter før arbejdet på begyndes.

START AF MASKINE

Udløs koblingen og placer gearstangen i det ønskede gear. Det kan være nødvendigt at trykke eller slå let på gearstangen for at tilkoble. Slip koblingshåndtaget langsomt og maskinen begynder at køre.

NB. Hvis kraftoverføringen er tilkoblet vil det automatisk slå fra, hvis maskinen sættes i bakgear.

START AF TILBEHØR

Udløs koblingen og tilkobl kraftoverføringen. Hæv motoromdrejningerne og slip koblingshåndtaget langsomt.

Når arbejdet er fuldført frakobles kraftoverføringen, hvorefter motoren stoppes, når motorstoppet deaktiveres

FEJLFINDING

Motor vil ikke starte, - **Benzin:**

- Stopkontakten er aktiveret
- Ingen benzin
- Benzinhanen er lukket
- Luftfiltret er stoppet
- Defekt tændrør
- Gammel benzin

Vil ikke tilkoble:

- Juster koblingskablet.

LANGTIDS OPBEVARING

I tilfælde af, at din maskine skal opbevares i længere tid bør du følge følgende fremgangsmåde for konservering.

Benzin/dieselmotor

- Tøm benzintanken og start motoren
Motoren vil gå i stå af sig selv.
- Kør motoren varm
- Tap motorolien af
- Påfyld straks ny motorolie
- Afmonter tændrøret og hæld en skefuld motorolie ned i motoren. Derefter trækkes 2-3 gange i startsnoren.
- Monter tændrøret igen.

VEDLIGEHOLDELSE OG SMØRRING

Korrekt vedligeholdelse og smøring forlænger levetiden af din fræser, og bør derfor følges nøje.

Motoren på din Pro•Trac har en indkøringsperiode på 5 arbejdstimer. Efter 5 timer skal motorolien skiftes, derefter er skifteintervallet på 50 timer eller mindst én gang om året. Tjek oliestanden hver gang du skal bruge din maskine.

Tjek olien på gearkassen for hver 50 timer og skift mindst én gang om året (fig. 12). Brug en 80/90 gearolie. Gearolien skal stå op til niveau skruen.

Hvis der er tegn på lækage, fugtige udtræk o.lign., skal olien tjekkes øjeblikkeligt.

Gearet på fræserhalen bør ligeledes tjekkes for hver 50 timer og skiftes én gang om året. Brug samme olie som på gearkassen (fig. 15, nr. 1)

BETJENINGSANORDNINGER (fig. 2)

- | | |
|---|-----------------------------|
| 1 | Koblingshåndtag |
| 2 | Frem - Bak |
| 3 | PTO tilkobling |
| 4 | Udløser for højdejustering. |
| 5 | Gashåndtag |
| 6 | Dødemandsstop |
| 7 | Lås for kobl. håndtag |

VINTEROPBEVARING

- Såfremt maskine ikke skal anvendes over en længere periode bør følgende regler for langtidsopbevaring følges.
- Rengør alle ydre dele på universaltraktoren. Eventuelle skader bør repareres inden oplagring.
- Alle bevægelige dele smøres med en olie med god indtrængnings evne, for at undgå rustdannelser.
- Tøm kaburator og brændstofsystem for brændstof, ved at lade motoren køre tør.
- Afmonter tændrøret og hæld 50 ml olie ned i åbningen. Træk langsomt i startsnoren, indtil der mærkes modstand. Derved forhindres rustdannelse i cylinderen.
- Skift olie på motor og gear.
- Er det en model med elektrisk start, skal batteriet afmonteres og lades fuldt op. Batteriet opbevares varmt og tørt.
- Afdæk maskinen og placer den i et tørt og rent lokale.

TILBEHØR

Den efterhængte fræser bruges til at forbehandle jorden for at klargøre den til så arbejdet. Fræseren er forsynet med et jordspyd der bestemmer jordsøgningen. Når jordspydet er helt oppe er der maksimal jordsøgning, og der arbejdes med maksimal fræserdybde.

Arbejdsdybden kan justeres ved at løfte/sænke knivene i forhold til fræserkassen. På toppen af fræserkassen (fig. 14), hvor fræserknivene er ophængt, er det muligt at ændre dybdegangen ved, at flytte den bolt der holder knivene. Der er tre huller foroven og tre huller forneden, hvor det er muligt at ændre højden på knivene i forhold til fræserkassen.

Maksimal fræserdybde er ca. 20 cm.

Texas Pro•Trac 550 R kan også monteres med fingerklipper og rotorklipper.

TRANSPORTHJUL

Den efterhængte fræser kan monteres med et transporthjul, som er en god ting, hvis maskinen skal transporteret over længere afstande.

MONTERING AF TILBEHØR

Det er utroligt vigtigt at monteringen af tilbehøret foregår på en korrekt forsvarlig måde.

- 1 Skub tilbehøret helt hen til udtaget
- 2 Skub tilbehøret lige på de to bolte
- 3 Påmonter møtrikkerne og spænd skiftevis
- 4 Tjek og efterspænd ofte.

Et skævt monteret tilbehør vil kunne ødelægge både boltene og kraftoverføringsbønsningen.

2000

USER MANUAL

TEXAS PRO•TRAC 550 TG



TEXAS Andreas Petersen A/S
Knullen 2 – DK-5260 Odense S
Tlf.: +45 63 95 55 55 Fax: +45 63 95 55 58
Internet adresse: www.texas.dk
E-mail adresse: export@texas.dk

USER MANUAL

Texas Pro•Trac 550

Thank you for choosing a Texas cultivator. We assure that the cultivator will meet your expectations of safety and performance.

Texas works constantly on continued development of machines and accessories and therefore we reserve the right to change the machines in shape, technique and design.

SAFETY INSTRUCTIONS

Before starting the engine this user manual shall be read and understood.

Persons under the age of 18 must not work with the machine.

When using the cultivator the safety regulations must be closely followed. Read the user manual thoroughly before you start your machine. Make sure that you are able to turn off the machine and engine in case of accident. All instructions concerning safety and maintenance of the cultivator serve for your safety.

A Pro Trac must not be used for any other work than described in the user manual.

Only use accessories and original spare parts recommended by Texas. Assembly of non-approved parts can cause increased risk of defect. Texas is not responsible for any damage caused because of use of unoriginal parts.

Before using the machine, the dealer should instruct the user in correct use and maintenance of the machine.

The one who operates the machine is responsible for other persons in the working area. Never sue the machine when children or animals are near by.

The machine must only be used by persons who are confident with the machine.

The machine must only be used by persons, who are not tired and in good shape. You must not use the machine under influence of alcohol, drugs or medicine.

The controlling units which were mounted from the side of the fabric, like the clutch cable, must not be removed

WORK WITH THE MACHINE

If the safety equipment is dismounted the machine must not be used again before it is remounted. When cleaning, maintaining and mounting of below-mentioned subjects the engine must be turned off and the sparking plug cover dismounted from the sparking plug.

- Maintenance of engine or machine
- Adjustments and repairs.
- Cleaning/removal of block ups.
- By transport and storage of the machine.

DAILY MAINTENANCE

On a daily basis clean the engine and transmission box for grass, leaves and oil in order to avoid fire.

When using a hose to clean the machine, you must never wash directly on the machine.

A damaged silencer causes too much noise and must be replaced.

By repairs you must only use original spare parts..

The number of revolutions of the engine has been determined from the fabric. The permanent max. adjustment protects the engine and must not be changed.

Inspect the machine for defect operation and safety labels. Should be replaced if defect.

WARNING LABELS

"CAUTION ROTATING KNIVES"

Using the machine on steep areas is dangerous. Only use the machine in areas where it can be manoeuvred safely.

When working with the machine use tight clothing, solid gloves and shoes/boots with non-skid soles..

STARTING

Inspect the engine for oil before every starting.

Inspect the machine for faults and wants every time it is used. Draw attention to the throttle control, clutch handle, switch, rotors and leakages in the fuel system.

You must only start the machine on an even surface. When the machine starts the user must have a firm gripping in the machine.

FILLING WITH FUEL

Be careful when filling with fuel as it is very flammable and contains poisonous gas arts and explosive material.

Never fill with fuel when the engine is running or is warm. Use a funnel or a container with a nozzle when filling with fuel.

Never smoke and avoid open fire during the filling.

If any fuel is spilled, clean this immediately and the machine is started at a distance from the filling area.

Draw attention to not spilling fuel on your work clothing. If this happens you have to redress.

Never fill with fuel in a closed room !

WORKING CONDITIONS

Before the machine is being used the handle must be adjusted to the correct working height.

Be careful when cultivation hard and stony ground. Always keep both your hands on the handlebar so that you can work in a calm and safe way.

The ground must always be cleaned from large stones, metal parts or other firm objects before the work is started. Watch out for hidden roots and logs.

Only operate the machine at appropriate lighting conditions. Work with machine in a calm and well-considered way.

Inspect bolts and nuts regularly. At noticeable vibrations the machine shall be stopped and inspected for any faults.

For safety reasons the engine shall always be stopped when you leave it.

TECHNICAL DATA PRO•TRAC 550 R

Engine	TG 500 5,0 HP	
Clutch	Dry single manual clutch	
Transmission box	1 gear forward and 1 reverse.	
Speed at 3600 engine revolutions and 13 x 5.00 - 6 wheel		
as tiller	Forward	1,4 km/h
	Reverse	2,2 km/h
as rotary mower	Forward	2,2 km/h
	Reverse	1,4 km/h
Power take off	Independant from transmission box 646 as tiller 965 as rotary mower.	
Wheel	13 x 5.00 - 6 air rubber.	
Tiller	50 cm. Adjustable from 33 cm.	
Handle	Adjustable in height/side. Turnable 180°.	
Width	50 cm. with tiller.	

BEFORE STARTING THE ENGINE

NOTE – ENGINE IS DELIVERED WITHOUT OIL!!!

Before start of engine the following shall be checked:

- The engine shall be placed in a horizontal position. Loosened the oil filling screw and fill with oil.
- Oil. If the oil level is below the mark on the oil stick, fill with oil. Always measure the oil level by putting the oil stick on top of the filling hole.
Use 15W-40 engine oil. It has been specially manufactured for air-cooled engines. If this oil type cannot be procured, a mineral oil with a viscosity of 15W-40 can be used.
- Use only oil of good quality as SC, SD, SE, SF and SG.
- Inspect all bolts and nuts, especially the ones fastening the accessories.
- Inspect that the PTO (power take off) is in neutral
- Inspect that the air filter is not blocked (dry filter) and that oil has been applied to the oil bath filter.
- Check oil height in the transmission box
- Fill with new gasoline leadless gasoline all octane, or diesel.
- When filling with fuel the machine must be placed in a horizontal position. Old fuel shall always be replaced.

See engine manual for further details.

START OF ENGINE

Apply the engine stop by pulling the clutch handle and locking it in an activated position (fig. 3) Open the petrol cock – press the throttle control halfway down and if the engine is cold activate the choke which is placed on the carburettor.

Start the engine by a quick pull in the starting cord. When the engine is started the choke lever is pushed slowly backwards while the engine is warming up. Wait 2-3 minutes before the work is started.

START OF MACHINE

Apply the clutch and choose the requested gear (5). It may be necessary to press or tap the gear lever in order to connect. Choose reverse or forward (6).
Release the clutch handle(1) slowly and the machine starts running.

NB. If the power take off is connected it will automatically disconnect when the machine is in reverse.

START OF ACCESSORY

Apply the clutch and connect the power take off. Increase the engine revolutions and release the clutch cable slowly.

When your work has been completed disconnect the power take off, whereafter the engine stops when the engine stop is deactivated.

TROUBLE SHOOTING

- The engine will not start, - **Gasoline:**
- The stop switch is activated
 - No fuel
 - The petrol cock is turned off
 - The air filter is blocked
 - Defect sparking plug
 - Old gasoline
- Cannot throw into gear:
- Adjust the clutch cable.

LONG TIME STORAGE

In case that your machine is being stored for a longer period of time, you must follow the following procedure.

- Gasoline
- Empty the fuel tank and start the engine
The engine will stop by itself
 - Run the engine warm
 - Drain for engine oil
 - Fill immediately with new engine oil
 - Dismount sparking plug and pour a spoonful of engine oil into the engine. Thereafter pull the starting cord 2-3 times
 - Remount the sparking plug.

MAINTENANCE AND LUBRICATION

Correct maintenance and lubrication prolongs the life of your cultivator and should therefore be followed closely.

The engine of your Pro Trac has a running-in period of 5 working hours. After 5 hours the engine oil should be replaced and thereafter the shifting interval is every 50 hours or once a year. Check the oil lever every time before you start your machine.

Check the oil on the transmission box every 50 hours and replace after 300 working hours
Use a 80/90 transmission oil. The transmission oil shall be fill to the screw (0.75L)

If there are any signs of leakage, moist extracts etc, the oil shall be checked immediately.

The transmission oil on the rotary tiller shall also be checked every 50 hours and replaced after 300 working hours. Use the same oil as on the transmission box.

OPERATION FEATURES

8	Clutch handle
9	Forward - Reverse
10	PTO
11	Release for height adjustment.
12	Throttle control
13	Dead man's handle
14	Lock for clutch handle

WINTER STORAGE

- If the machine is not to be used for a longer period of time the following prescription shall be followed.
- Clean all external parts on the machine. Any damages should be repaired before storage.
- All moving parts shall be lubricated with oil with good penetrating abilities in order to avoid corrosion.
- Empty the carburettor and fuel system of fuel by letting the engine run dry.
- Dismount the sparking plug and pour 50 ml of oil into the opening. Draw the starting cord until you feel resistance. Thereby you avoid corrosion in the cylinder.
- Change oil on engine and transmission.
- Cover the machine and place it in a dry and clean room.

TILLER

The rotary tiller is used to prepare the ground for the seeding work. The tiller is equipped with an earth auger which determines the working depth.

The working depth can be adjusted by lifting/lowering the knives in comparison the tiller box. On the top of the tiller box, where the tiller knives hang, it is possible to change the depth by moving the bolt that fastens the knives. You see three holes in the top and three holes below where it is possible to adjust the height of the knives in comparison to the tiller box.

Max cultivating depth is app. 20 cm. .

Pro•Trac 55O R can be mounted with a side adjustable broom of 80 cm. It can also be used with a rotary mower and a cutter bar.

TRANSPORT WHEEL

The rotary tiller can be mounted with a transport wheel, which is a good thing, when the machine is to be transported longer distances.

MOUNTING OF ACCESSORY

It is very important you mount the accessory correctly.

- 5 Place the accessory so that it meets the power take off
- 6 Push the accessory evenly on the two bolts
- 7 Mount the bolts and fasten
- 8 Inspect and fasten on a regular basis.

An uneven mounting will destroy both bolts and the bushing of the power take off.

ILLUSTRATIONS

