

**ZENOAH
KOMATSU**



< PROVISIONAL >

PARTS LIST

BRUSHCUTTERS

BC341FW

1995

APPLICABLE SERIAL NUMBERS:

DRIVE UNIT 504001 and up
ENGINE UNIT 500001 and up

DECEMBER 1994

BC341FW

Fig.1 DRIVE UNIT & ACCESSORIES





Fig.1 DRIVE UNIT & ACCESSORIES

Key#	PART NUME -R	DESCRIPTION	QTY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	QTY /UNIT	NOTE
1	3541-11102	HOUSING COMP	1		61	3540-14900	BRACKET ASSY	1	
2	3541-11112	HOUSING	1		62	3540-14910	BRACKET	1	
3	3541-11120	SEAL	1		63	3540-14920	CAP, lower	1	
4	0260-20610	SCREW	1		64	3540-14930	CAP, upper	1	
5	3541-11130	SPACER	1		65	3540-14140	ABSORBER	2	
6	3530-11310	DRUM	1		66	3540-14150	CRAMP (A)	1	
7	06004-06202	BEARING	1		67	3540-14160	CRAMP (B)	1	
8	04064-01510	RING	1		68	01252-30525	BOLT	6	
9	04065-03515	RING	1		69	01252-30530	BOLT	4	
10	3540-11410	SPACER	1		70	3530-14171	SPACER	2	
11	6468-91150	BOLT	4		71	6465-14200	HANDLE COMP	1	
12	3530-12103	PIPE COMP	1		72	6350-14230	HANDLE	1	
13	3263-11410	RING	1		73	6489-24000	GUARD ASSY	1	
14	3263-11420	PLATE	1		74	6489-24110	GUARD	1	
15	3530-12211	SHAFT	1		75	6489-24200	PLATE COMP	1	
16	2175-84000	LEVER ASSY	1		76	6489-24210	PLATE	1	
17	1638-84110	GRIP, right	1		77	6489-24220	BLADE	1	
18	1638-84120	GRIP, left	1		78	00277-10412	SCREW	1	
19	1638-84130	LEVER, throttle	1		79	6489-24120	PLATE	1	
20	1638-84140	LEVER, safety	1		80	01252-30516	BOLT	4	
21	1638-84150	LOCK	1		81	01601-20513	WASHER → (228-20335)	4	
22	1638-84160	BAND	1		82	6251-15910	COVER	1	
23	2175-84300	CABLE COMP	1		83	3523-17112	PROTECTOR	1	
24	1638-84170	SPRING	1		84	6220-17201	HARNES ASSY	1	
25	1638-84180	SPRING	1		85	3540-93120	BAND	1	
26	0263-60620	SCREW	1		86	3542-91000	TOOL SET	1	
27	1638-84190	NUT	1		87	1030-91340	SCREWDRIVER	1	
28	0260-60535	SCREW	1		88	3114-91160	SOCKET	1	
29	1638-84210	NUT	1		89	09007-00425	WRENCH	1	
30	1638-84220	SCREW	1		90	09007-00528	WRENCH	1	
31	6550-11420	HANGER	1		91	3540-91110	BAR	1	
32	0224-10616	BOLT	1		92	3540-91120	SPANNER	1	
33	3541-11441	BRACKET COMP	1		93	3540-13283	COVER	1	†
34	0224-00635	BOLT	1		94	3140-13261	SHAFT	1	†
35	3540-11460	NUT	1		95	6298-14343	SAW 255-4T	1	‡
36	01642-20608	WASHER	1		9798	6210-92500	STABILIZER ASSY	1	‡
37	3541-11450	SPACER	1		9897	3130-15312	SRABILIZER	1	‡
38	0224-00625	BOLT	1		9998	3530-15331	HOLDER	1	‡
39	01642-20608	WASHER	1		10099	3548-15351	SHAFT	1	‡
40	6522-13000	GEARCASE ASSY	1		100	06004-06003	BEARING	1	‡
41	6522-13110	GEARCASE	1		101	3548-15370	COVER	1	‡
42	06000-06000	BEARING	1		102	3548-15380	SPACER	1	‡
43	06000-06202	BEARING	1		103	0212-50612	BOLT	3	‡
44	3130-13141	SEAL	1		104	0290-20615	WASHER	3	‡
45	04065-03515	RING	1		105	3239-91310	SOCKET	1	‡
46	3540-13212	SHAFT	1		106	6298-15343	SAW 255-8T	1	‡
47	3540-13220	GEAR	1						
48	6522-13310	PINION	1						
49	06000-06000	BEARING	1						
50	06001-06000	BEARING	1		†	Not attached to the model for Italy			
51	3180-13330	RING	1		‡	Not attached to any model excepting that for Italy			
52	04065-02612	RING	1						
53	6251-13240	HOLDER (A)	1						
54	3540-13251	HOLDER (B)	1						
55	3544-13280	WASHER	1						
56	01643-31032	WASHER	1						
57	3540-13290	BOLT	1						
58	3540-13260	BOLT	1						
59	01252-30510	BOLT	1						
60	0224-40610	BOLT	1						

Reservedelsliste for Feed-Matic snørehoved

for 'TEXAS' buskryddere

1992/1



Pos.nr.	Best.nr.	Tekst
01	10-101007	Adapter for BC 220
01a	10-101008	Adapter for 340 M
01b	10-101010	Adapter for 431 M
02	10-101061	Spolehus
03	10-106003	Snørestyr
04	10-101030	Spole
05	10-103025	Låsering
06	10-101053	Bund for spolehus
06a	10-201003	Komplet bund pos. 5-12
07	10-107006	Fjeder
08	10-101069	Fjederholder
09	10-101070	Kugleskål
10	10-102073	Stålkugle
11	10-101071	Kugleholder
12	10-101056	Bolt
13	10-109006	Nøgle
14	22007100	Snørehoved for BC 220 7 MM
15	34008125	Snørehoved for 340 M 8 MM
16	43110125	Snørehoved for 431 M 10 MM

Fig.2 ENGINE UNIT




Fig.2 ENGINE UNIT

Key#	PART NUMBER	DESCRIPTION	QTY UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	QTY UNIT	NOTE
1	1650-1212	CYLINDER	1		66	1600-75180	TAPE	1	
2	3310-12281	BOLT	4		67	1600-75201	PULLEY ASSY	1	
3	0260-30560	SCREW	2		68	1600-75220	RATCHET	1	
4	1650-13120	GASKET	1		69	1600-75230	SPRING	1	
5	1650-13130	GASKET	1		70	1034-72180	E-RING	1	
6	1650-13141	GASKET	1		71	0263-90520	SCREW	4	
7	1650-13150	GASKET	1		72	1666-81002	CARBURETOR ASSY	1	
8	1650-13160	INSULATOR	1		73	1650-81122	CAP	1	
9	1650-21102	CRANKCASE COMP	1		74	1650-81150	VALVE, throttle	1	
10	1650-21140	GASKET	1		75	1030-81000-14	SPRING	1	
11	06030-06201	BEARING	2		76	1030-81000-17	RECEIVE	1	
12	2169-21210	SEAL	1		77	1650-81210	NEEDLE, Jet	1	
13	1650-21220	SEAL	1		78	1030-81000-18	CLIP	1	
14	04065-03212	RING	1		79	1400-81230	JET, needle	1	
15	01252-30530	BOLT	4		80	1650-81240	JET, main	1	
16	2155-21311	GUARD	1		81	1335-81180	FLOAT	1	
17	0263-90514	SCREW	2		82	1400-81340	HINGE	1	
18	1650-41111	PISTON	1		83	1400-81350	PIN	1	
19	1650-41210	RING	2		84	1650-81361	VALVE, needle	1	
20	1650-41310	PIN	1		85	1650-81251	SCREW, idle adjust	1	
21	3310-41320	RING	2		86	1650-81260	SPRING	1	
22	3310-41410	BEARING	1		87	1403-81500	FUEL SHUTOFF	1	
23	1650-41510	WASHER	2		88	1400-81540	O-RING	1	
24	1650-42000	CRANKSHAFT COMP	1		89	0260-10410	SCREW	2	
25	1130-43260	SHIM, 0.3t	0/1		90	1400-81320	PACKING	1	
26	1140-43250	SHIM, 0.1t	0/1		91	1400-81310	CHAMBER	1	
27	1650-43230	NUT	2		92	1400-81650	SCREW	1	
28	1000-43240	KEY	1		93	1400-81660	PACKING	1	
29	1400-51110	SHOE	2		94	1141-81120	CAP	1	
30	1400-51220	SPRING	1		95	1650-81710	PIPE	1	
31	1200-51211	SCREW	2		96	0260-10412	SCREW	2	
32	1200-51230	WASHER	2		97	1400-82001	CLEAVER ASSY	1	
33	1200-51240	WASHER	2		98	1400-82112	BODY	1	
34	2155-71110	ROTOR	1		99	1400-82120	COVER	1	
35	2155-71200	COIL ASSY	1		100	1418-82130	ELEMENT	1	
36	2155-71220	CORD	1		101	1400-82140	SCREEN	1	
37	2616-71320	CAP	1		102	1133-82060	LABEL	1	
38	5500-72130	GROMMET	1		103	0260-30422	SCREW	2	
39	1100-72120	GROMMET	1		104	2117-85000	TANK ASSY	1	
40	1900-72111	CAP	1		105	2133-85300	CAP ASSY	1	
41	1900-72120	SPRING	1		106	1400-85325	CAP, inner	1	
42	0263-90520	SCREW	2		107	1030-85140	ELEMENT	1	
43	1650-15110	MUFFLER	1		108	1600-85322	PACKING	1	
44	0263-90512	SCREW	1		109	3317-57242	STOPPER	1	
45	1650-15150	BOLT	2		110	1400-85103	JOINT ASSY	1	
46	1650-15210	COVER	1		111	1400-85140	GROMMET	1	
47	0263-90512	SCREW	3		112	1000-08050	TUBE	1	
48	1650-21320	COVER	1		113	1410-86130	CLIP	1	
49	3310-12281	BOLT	4		114	1410-86130	CLIP	1	
50	1100-72120	GROMMET	1		115	1650-86212	SUPPORT	1	
51	1650-31150	GROMMET	1		116	1600-86120	SCREW	3	
52	1654-32111	COVER	1		117	1400-86250	COLLAR	1	
53	0263-90512	SCREW	2		118	1400-86280	COLLAR	2	
54	3540-93110	STAND	1		119	1400-86271	CUSHION	2	
55	3310-31720	BOLT	2		120	1400-86280	WASHER	2	
56	2155-71240	CORD	1		121	1660-31121	LABEL	1	
57	2116-71250	CORD, earth	1		122	1654-75411	LABEL	1	
58	1216-73110	SPARK PLUG	1						
59	1600-75001	STARTER ASSY	1						
60	1600-75101	RECOIL ASSY	1						
61	1600-75130	RECOIL ASSY	1						
62	1600-75120	REEL	1						
63	1600-75151	SCREW	1						
64	1600-75160	ROPE	1						
65	1140-75320	KNOB	1						