



Reservedelsliste TEXAS

grus- & saltspreder DL48 1987/1




RESERVEDELSLISTE FOR TEXAS GRUS- OG SALTSPREDER DL 48 1987/1

BILLED NR.	BESTILLINGS NR.	TEKST OG BESKRIVELSE
01	9-480-001	Trekantet skærm
02	90100691	Låsemøtrik
03	9-480-003	Røreværk
04	90102730	Sætskrue
05	9-480-005	Gevindbøsning
06	9-480-006	Tragtbeholder
07	90100085	Brædebolt
08	9-480-008	Højre holder for prelleplade
09	9-480-009	Venstre holder for prelleplade
10	90102310	Planskive
11	90100662	Møtrik
12	9-480-012	Plasthåndhjul
13	9-480-013	Prelleplade
14	90100089	Brædebolt
15	9-480-015	Støttekonsol for tragtbeholder
16	90102310	Planskive
17	90100662	Møtrik
18	9-480-018	Håndgreb
19	9-480-019	Reguleringsanordning
20	90100662	Møtrik
21	90102310	Planskive
22	9-480-022	Venstre støtte for trækstang
23	9-480-012	Plasthåndhjul
24	90102310	Planskive
25	90102748	Sætskrue
26	9-480-026	Trækstang
27	90102310	Planskive
28	90100662	Møtrik
29	9-480-029	Venstre trækstangskonsol
30	9-480-012	Plasthåndhjul
31	90102748	Sætskrue
32	9-480-032	Nylonbøsning
33	90102310	Planskive
34	90100692	Låsemøtrik
35	9-480-035	Beskyttelseskærm
36	9-480-036	Højre trækstangskonsol
37	90102749	Sætskrue
38	9-480-038	Aksel
39	9-480-039	Medbringer
40	9-480-040	Venstre traktorhjul
41	90102899	Stålbolt
42	9-480-042	Gearbox
43	9-480-043	Spidshjul
44	9-480-032	Nylonbøsning
45	9-480-045	Højre støtte for trækstang
46	90100662	Møtrik
47	90102310	Planskive
48	90102741	Sætskrue
49	9-480-049	Låge
50	9-480-050	Selvlåsende ringmøtrik
51	9-480-051	Sprædeplade
52	90102454	Fjedersplit
53	90101600	Olietætning
54	90102615	Seegerring
55	90200225	Leje
56	9-480-056	Bøsning
57	90200225	Leje
58	90104467	Rørstift
59	90102730	Sætskrue
60	9-480-060	Geardrev
61	90100691	Låsemøtrik
62	9-480-032	Nylonbøsning
63	9-480-063	Dæksel til gearbox
64	90102195	Låseskive
65	90100667	Møtrik
66	9-480-032	Nylonbøsning
67	9-480-067	Højre traktorhjul
68	9-480-032	Nylonbøsning
69	90102318	Planskive
70	90102454	Fjedersplit



Pos.	Denomination	Q.	Pos.	Denomination	Q.
1	Seat for 50lt capacity hopper	1	44	Outgoing shaft	1
2	50lt capacity round shaped hopper	1	45	Cotter pin	1
2a	100lt capacity round shaped hopper	1	46	Spreader disc	1
2b	160lt capacity round shaped hopper	1	47	Self-locking ring nut	1
3	Spacer ring for 100-160lt capacity round shaped hopper	1	48	Mobile shutter	1
4	Stirrer	1	49	Baffle	1
5	Hex. screw M6 x 35	2	50	Cyl. screw M8 x 20	2
6	Self-locking nut M6	3	51	Towing rudder	1
7	Threaded bushing	1	52	R.H. baffle connection	1
8	Cyl. screw M8 x 40	1	53	L.H. baffle connection	1
9	Washer ϕ 8 x 17	14			
10	Nut M8	13			
11	Round shaped hopper supporting bracket	1			
11a	Square shaped hopper supporting bracket	1			
12	Handles for manual control	1			
13	Handles hand grip	2			
14	Guard	1			
15	Hex. screw M8 x 40	8			
16	Hex. screw M8 x 16	2			
17	L.H. rod for rudder adjustment	1			
18	R.H. rod for rudder adjustment	1			
19	Shutter adjusting device	1			
20	Hand wheel M6 x 15	4			
21	L.H. rudder connection	1			
22	R.H. rudder connection	1			
23	Nylon made bushing ϕ 19	4			
24	Bearing pad for manual control	2			
25	Wheel 350/85	2			
26	Hex. screw M6 x 40	1			
27	Hex. screw M6 x 90	4			
28	Axle	1			
29	Spring washer ϕ 6	4			
30	Nut M6	4			
31	Washer ϕ 8 x 32	1			
32	Spring washer ϕ 8	1			
33	Hex. screw M8 x 25	1			
34	Shutter regulation knob	1			
35	Box	1			
36	Box cover	1			
37	Gear Z64	1			
38	Gear Z16	1			
39	Spring pin ϕ 5 x 20	1			
40	Bearing 6202	2			
41	Spacer	1			
42	Snap ring ϕ 35	1			
43	Seal ring ϕ 16 x 35 x 7	1			

RONDINI F.lli S.n.c
 COSTRUZIONE MACCHINE AGRICOLE
 42010 S. GIOVANNI DI NOVELLARA (RE) Italy
 TEL. (0522) 667148



SPARE PARTS CATALOG

FERTILIZER SPREADER MOD. Jardin SPT

Mod : STP50 - 100 - 160