


**Reservedelsliste  
Ersatzteilliste  
Spare Parts List  
Liste De Pièces Detachées**

# **Power Flex System**

**Pumpe  
Pumpe  
Pump  
Pompe**

Art nr.: PFS-pumpe 96  
Fra serie nr.: 10000



Nr.	Best.nr.	Stk	Beskrivelse	Bezeichnung D	Description GB	Description F
1	92501014	1	Slange nippel	Schlauchnippel	Tupenipple	Tube raccord
2	92501013	1	Bøsning/omløber	Buchse	Bushing	Entretoise
3	92501015	1	Brystnippel	Brustnippel	Breastnipple	Mamelon
4	92501030	1	Prop	Plastikstopfen	Plug	Bouchon
5	92501028	1	O-ring	O-ring	O-ring	O-rondelle
6	92501035	1	Pumpehus-krop	Pumpengehäuse	Pump housing	Caisse de pompe
7	92501016	10	Møtrik	Mutter	Nut	Ecrou
8	92501029	1	Prop	Plastikstopfen	Plug	Bouchon
9	92501028	1	O-ring	O-ring	O-ring	O-rondelle
10	90102743	2	Skrue	Schraube	Screw	Vis
11	90102310	2	Skive	Scheibe	Washer	Rondelle
12	92501026	1	Kontraventil	Absperrventil	Non-return valve	Soup. de retenve
13	92501025	1	Skrue	Schraube	Screw	Vis
14	92501024	2	Skrue	Schraube	Screw	Vis
15	92501023	1	Hus for Løbehjul	Laufradgehäuse	Rotorblade house	Boîte p. coronne
16	92501018	1	O-ring	O-ring	O-ring	O-rondelle
17	90107680	1	Skrue	Schraube	Screw	Vis
18	92501019	1	O-ring	O-ring	O-ring	O-rondelle
19	92501022	1	Løbehjul	Laufrad	Rotor blade whe.	Couronne mobile
20	92501033	1	Skive (0,15 mm)	Scheibe	Washer	Rondelle
	92501034	1	Skive (0,40 mm)	Scheibe	Washer	Rondelle
21	92501020	1	O-ring	O-ring	O-ring	O-rondelle
22	92501032	1	Not	Nut	Groove	Engraisseur
23	90107685	4	Skrue	Schraube	Screw	Vis
24	92501019	4	O-ring	O-ring	O-ring	O-rondelle
25	92501021	1	Akseltætning	Achsepackung	Axle tightening	Axe obturation
26	92501017	1	Pumpekonsol	Pumpenkonsole	Pumpconsole	Pompe console
27	92501027	10	Skrue	Schraube	Screw	Vis
28	92501006	1	Lejebuk	Lagerbock	Bearing frame	Cheralet de palier
29	90200234	1	Leje	Lager	Bearing	Palier
30	92501001	1	Aksel	Achse	Axle	Axe
31	90102310	2	Skive	Scheibe	Washer	Rondelle
32	90102741	2	Skrue	Schraube	Screw	Vis
33	90200222	1	Leje	Lager	Bearing	Palier
34	90104480	1	Rørstift	Spannstift	Pin	Vie de serrage
35	92500013	1	Firkantbøs	Buchse	Bushing	Entretoise
36	92501003	1	Lejehus	Lagergehäuse	Bearing Housing	Logement
37	90102741	2	Skrue	Schraube	Screw	Vis
38	90102310	2	Skive	Scheibe	Washer	Rondelle
39	92501012	1	Stålbøjle	Stahlbügel	Steelshackle	Étrier
40	92500002	1	Støvhætte	Staubkappe	Dust cap	Boutom
41	90100692	1	Låsemøtrik	Mutter	Lock nut	Ecrou
42	92501007	1	Rørholder	Rohrständer	Tupeholder	Étau à tupe
43	90102310	2	Skive	Scheibe	Washer	Rondelle
44	90100692	2	Møtrik	Mutter	Nut	Ecrou
45	92501009	1	Konsol	Konsole	Console	Console
46	90102453	1	Split	Federsplit	Cotter pin	Coupille
47	90102310	2	Skive	Scheibe	Washer	Rondelle
48	90100692	2	Låsemøtrik	Mutter	Nut	Ecrou
49	90102198	2	Låseskive	Scheibe	Washer	Rondelle frein
50	90100662	2	Møtrik	Mutter	Nut	Ecrou
51	90102198	2	Låseskive	Scheibe	Washer	Rondelle
52	90100662	2	Møtrik	Mutter	Nut	Ecrou
53	90102453	1	Split	Federsplit	Cotter pin	Coupille
54	92501011	1	Stativ	Ständer	Stand	Châssis
55	90000056	1	Splitbolt	Steckbolzen	Cotter bolt	Boulon à goupille
56	90000057	1	Split	Federsplit	Cotter pin	Goupille