




G150



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1.		404313	HÅNDTAG	HANDLE
2.		404314	POTENTIOMETER	POTENTIOMETER
3.		404315	U-KROG	HOOK
4.		404316	ØVERSTE STØTTE	UPPER SUPPORT
5.		404317	REM	BELT UPPER
6.		404318	CONTROLLER	CONTROLLER
7.		404319	BÆRE REM	BELT MID
8.		404320	HÅNDHJUL	NUT
9.		404321	FIXERINGSPLADE	FIXING PLATE
10.		18120002-0	BATTERI 12V 18AH	BATTERY 12 V
10-1.		404322	TASKE FOR BATTERI	BAG FOR BATTERY
11.		404323	BATTERIKASSE	BATTERY BOX
15.		404328	MOTOR	ENGINE
16.		404329	SKÆRM VED FORHJUL / BESLAG	FENDER / BRACKET
17.		404330	FORHJUL	FRONT WHEEL
18.		404332	NEDERSTE BUNDSTØTTE	SUPPORT LOWER
19.		408057	STØTTE	SUPPORT LOWER FOR BAG
20.		404340	BATTERI INDIKATOR	BATTERY INDICATOR
21.		404341	NOTERINGSPLADE	SCOREBOARD
22.		404342	ØVERSTE STANG	TUBE UPPER
23.		404343	BESLAG	BRACKET
24.		404344	MELLEMSTE STANG	TUBE MIDDLE
25.		404345	NEDERSTE STANG	TUBE LOWER
26.		404346	BESLAG	BRACKET





32

33



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
27.		404347	STANG FOR HJUL VENSTRE	BAR FOR WHEEL LEFT
28.		404348	STANG FOR HJUL HØJRE	BAR FOR WHEEL RIGHT
29.		404349	BESLAG FOR HJULSTÆNGER	BRACKET
30.		404350	MONTERINGSBESLAG	MOUNTING BRACKET
31.		404576	HJUL AKSEL	SHAFT
32.		404352	LADER GOLFOG N G105 / G105	CHARGER
33		404353	KABEL MED SIKRING	CABLE WITH FUSE



404632



404633



404634



404635



404636



404637



404638



404639



404640



404641



**404642
6MM**



404643



404644



404645



404646



404479



404647



404648



404649



404314



404650



404651



404652



404653

		
<p>404654</p>	<p>404655</p>	<p>404656</p>
		
<p>404657</p>	<p>404658 4,5 x 16 MM</p>	<p>405003 Hun / Female</p>
		<p>SIKRING FUSE 30A MINI</p>
<p>405002 Han / Male</p>	<p>404353</p>	<p>405160</p>
		
<p>408519</p>	<p>408520</p>	<p>408521</p>
		
<p>408522</p>		

G105 / 150



404324



404326
Lås / Lock



404325
Venstre /
Left



405162
Højre /
Right

