



PARK SVÆVER



PARK SVÆVER SPARE PARTS LIST

No:	Part no:	Description		No:	Part no:	Description
1	860300	screw		25	860324	washer
2	860301	ward dust cap		26	860325	pin shoe
3	860302	screw		27	860326	blade
4	860303	upper cover		28	860327	handle
5	860304	brush		29	860328	connector
6	860305	brush tube		30	860329	knob
7	860306	screw		31	860330	washer
8	860307	brush-shelf frame		32	860331	screw
9	860308	back cap		33	860332	long handle
10	860309	rubber shoe		34	860333	hook
11	860310	bearing		35	860334	capacitor
12	860311	stator		36	860335	switch
13	860312	armature		37	860336	cord
14	860313	front cap		38	860337	cord armor
15	860314	spring washer		39	860338	cord plug
16	860315	screw		40	860339	switch handle
17	860316	special screw		41	860340	screw
18	860317	cabinet		42	860341	push-botton spring
19	860318	insert nut		43	860342	push-botton
20	860319	screw		44	860343	screw
21	860320	wind impeller		45	860344	cord clamp
22	860321	knife plate		46	860345	screw
23	860322	bolt		47	860346	upper switch box
24	860323	rivet		48	860347	down switch box