


POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	431494	TÆNDRØR RCJ6Y	SPARK PLUG RCJ6Y
2	4	431495	BOLT M5X20 M5X20	BOLT M5X20
3	1	431496	CYLINDER	CYLINDER
4	1	431497	PAKNING CYLINDER	GASKET, CYLINDER
5	2	431498	STEMPEL RING	RING, PISTON
6	1	431499	STEMPEL	PISTON
7	1	431500	PINBOLT STEMPEL 8X28 8X28	PIN, PISTON 8X28
8	2	431501	LÅSERING	RING, SNAP
9	1	431502	NÅLE LEJE	NEEDLE BEARING
10	2	431503	SKIVE	WASHER
11	1	431504	KRUMPTAP AKSEL KPL.	CRANK SHAFT ASSY
12	2	431505	LEJE 6001/P5 6001/P5	BEARING 6001/P5
13	2	431506	PIN B3X10 B3X10	PIN B3X10
14	1	431507	PAKNING KRUMPTAPHUS	GASKET, CRANKCASE
15	1	431508	KRUMPTAPHUS BAGERSTE	REAR CRANKCASE
16	2	431509	PAKDÅSE 12X22X7 12X22X7	OIL SEAL 12X22X7
17	2	431510	STOP RING	STOP RING
18	1	431511	STARTER TRÆK	STARTER PULLEY
19	2	431512	STARTER PAL FJEDER	STARTER PAWL SPRING
20	2	431513	STARTER PAL	STARTER PAWL
21	1	431514	PASFEDER	PARALLEL KEY
22	1	431515	KRUMPTAPHUS FORREST	FRONT CRANKCASE
23	3	431516	BOLT M5X30 M5X30	BOLT M5X30
24	1	431517	SVINGHJUL	ROTOR
25	1	431518	VARMEBESTANDIG PAKNING	GASKET, INSULATOR
26	1	431519	INSULATOR	INSULATOR
27	2	431520	BOLT M5X20 M5X20	BOLT M5X20
28	1	431521	KARBURATOR PAKNING	GASKET, CARBURETOR
29	1	431522	KARBURATOR KPL. H619-00-01	CARBURETOR COMP
30	1	431523	CHOKER HÅNDTAG	CHOKE HANDLE
31	1	431524	LUFTFILTERHUS INDVENDIG	CLEANER INSIDE COVER
32	1	431525	CHOKER SPJÆLD	CHOKE
33	1	431526	SKRUE ST4x10 ST4x10	BOLT ST4x10
34	1	431527	LUFTFILTER ELEMENT	AIR FILTER ELEMENT
35	2	431528	BOLT M5X60 M5X60	BOLT M5X60
36	1	431529	LUFTFILTERHUS DÆKSEL	COVER, CLEANER
37	1	431530	SKRUE FOR DÆKSEL	KNOB, COVER
38	1	431531	UDSTØDNINGSPAKNING	GASKET, MUFFLER
39	1	431532	UDSTØDNING KPL.	MUFFLER ASSY
40	2	431533	SKIVE	WASHER
41	3	431508	KRUMPTAPHUS BAGERSTE	REAR CRANKCASE
42	2	431534	MASKINSKRUE M5X50 M5X50	SCREW M5X50
43	2	431535	SKIVE	WASHER
44	2	431536	AFSTANDSSKIVE	SPACE, IG COIL
45	1	431537	STOP LEDNING	STOP WIRE
46	1	431538	TÆNDPOLE KPL.	IGNITION COIL COMP
47	2	431539	SKRUE M4X20 M4X20	SCREW M4X20



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	431540	BOLT M4X14 M4X14	BOLT M4X14
2	1	431535	SKIVE	WASHER
3	1	431541	BLÆSER DÆKSEL	FAN NET COVER
4	1	431542	SKIVE	WASHER
5	1	431543	FJEDER	WREST SPRING
6	1	431544	SKIVE	WASHER
7	1	431545	STIFT FOR FJEDER	WREST SPRING SHAFT
8	1	431546	HÅNDTAG VENSTRE GUMMIBELAGT	LEFT HANDLE RUBBER COVER
9	1	431547	STOP KONTAKT KPL.	STOP SWITCH COMP
10	1	431548	LEDNING FOR STOPKONTAKT	STOP WIRE
11	1	431549	GASHÅNDTAG	THROTTLE LEVER HANDLE
12	1	431550	STIFT FOR GASHÅNDTAG	THROTTLE LEVER SHAFT
13	5	431551	SKIVE	WASHER
14	4	431516	BOLT M5X30 M5X30	BOLT M5X30
15	4	431552	PEDESTAL	PEDESTAL
16	4	431553	SKRUE M5x10 M5X10	SCREW M5x10
17	1	431554	BLÆSERVINGE	IMPELLER
18	1	431555	BLÆSERHUS BAGERSTE	REAR COCHLEA CASS
19	8	431556	QC/T713 / MANGLER TEGNING	QC/T713 MISSING DRAWING
20	4	431557	SKIVE	WASHER
21	1	431558	BLÆSERHUS FORREST	FRONT COCHLEA CASE
22	1	431559	BRÆNDSTOFTANK	FUEL TANK
23	1	431560	HÅNDTAG NEDERSTE	LOWER HANDLE
24	1	431561	HÅNDTAG ØVERST	UPPER HANGLE
25	1	431546	HÅNDTAG VENSTRE GUMMIBELAGT	LEFT HANDLE RUBBER COVER
26	1	431562	SKRUE 4.2x10 ST4.2X10	SCREW4.2x10
27	4	431563	SKRUE 5X20 ST5X20	SCREW 5X20
28	2	431548	LEDNING FOR STOPKONTAKT	STOP WIRE
29	1	431564	MOTOR BENZIN	GASOLING ENGING
30	1	431565	BRÆNDSTOF RETUR SLANG (L=70) L=70	RETURN FUEL PIPE(L=70)
31	1	431566	GUMMIPROP FOR BRÆNDSTOFTANK	FUEL PIPE RUBBER BUNG
32	1	431567	BRÆNDSTOF SUGESLANGE (L=220) L=220	INLET FUEL PIPE(L=220)
33	1	431568	BRÆNDSTOF FILTER	FILTER CLEANER
34	1	431569	TANKDÆKSEL	FUEL CAP
35	1	431570	GASKABEL KPL.	THROTTLE WRIE COMP
36	1	431571	REKYLSTART SPOLE	STARTER POPE REEL
37	1	431572	REKYLSTART FJEDER	COLE SPRING
38	1	431573	REKYLSTART DÆKSEL	RECOIL COVER
39	3	431574	SKRUE M5x30 M5X30	SCREW M5x30
40	1	431575	STARTSNOR	STARTER POPE
41	1	431576	STARHÅNDTAG	STARTER HANDLE
42	1	431577	BLÆSERØR ØVERSTE	BLOW THE BREEZE TUBE A
43	1	431578	BLÆSERØR NEDERSTE	BLOW THE BREEZE TUBE B
44	1	431579	SKIVE	WASHER

POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
45	1	431580	SKIVE	WASHER
46	1	431581	SKIVE	WASHER
47	1	431582	MØTRIK M8x1 M8X1	NUT M8x1
48	1	431583	BØS	BUSHING
49	1	431584	STARTSNOR GUIDE	GUIDE,ROPE
50	2	431585	SKRUE M5x30 M5X30	SCREW M5x30
51	1	431586	SKRUE M5x10 M5X10	SCREW M5x10