



Item no:	Spare part no:	Part Description		Item no:	Spare part no:	Part Description
1	290100	PWB		33	290132	SWITCH
2	290101	KNOB		34	290133	POSITION PIECE
3	290102	POTENTIOMETER		35	290134	RIGHT HOUSING
4	290103	POWER CORD		36	290135	SHAFT
5	290104	CABLE GUARD		37	290136	LOCK
6	290105	SCREW		38	290137	WASHER
7	290106	CABLE CLAMP		39	290138	SCREW
8	290107	LEFT HOUSING		40	290139	RUBBER WASHER
9	290108	ADJUSTMENT KNOB		41	290140	REAR LEFT TUBE
10	290109	BAG HOLDER		42	290141	REAR RIGHT TUBE
11	290110	PLASTIC BELT FOR COLLECTION BAG		43	290142	FRONT BEARING HOLDER
12	290111	COLLECTION BAG		44	290143	SCREW
13	290112	BELLOWS PARTS		45	290144	FRONT LEFT TUBE
14	290113	SPLINE SHAFT		46	290145	FRONT RIGHT TUBE
15	290114	WASHER		47	290146	NOZZLE (PATIO)
16	290115	SPRING		48	290147	WASHER
17	290116	BLOCK		49	290148	DECORATE COVER
18	290117	SCREW		50	290149	WHEEL
19	290118	SCREW		51	290150	NUT
20	290119	IMPELLER		52	290151	WHEEL
21	290120	MICROSWITCH		53	290152	SCREW
22	290121	RING		54	290153	SCREW
23	290122	SCREW		55	290154	RIGHT GRIP
24	290123	RUBBER MAT		56	290155	SCREW
25	290124	BEARING		57	290156	LEFT GRIP
26	290125	CAPACITOR		10,11+12	290157	BAG HOLDER CPL. WITH BAG +BELT
27	290126	ROTOR			290158	SHOULDER STRAP
28	290127	WAVE GASKET		51,55-57	290159	HANDLE GRIP CPL. ASSEMBLED
29	290128	STATOR		6,47-50	290160	PATIO CPL ASSEMBLED
30	290129	INDUCTANCE		6,41+42	290161	REAR TUBE PRE ASSEMBLED
31	290130	REAR BEARING HOLDER		6,45+46	290162	FRONG TUBE PRE ASSEMBLED
32	290131	CARBON BRUSH HOLDER		37-39	290163	LOCK PRE-ASSEMBLED