




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
5	1	424799	PAKNING	GASKET, CYLINDER HEAD
6	1	421820	VENTILDÆKSEL	COVER SUBASSEMBLY, CYLINDER HEAD
7	1	424800	PAKNING	GASKET, CYLINDER HEAD COVER
8	1	424801	ÅNDERØR	TUBE, BREATHER
9	1	421822	BOLTSÆT	BOLT SUBASSEMBLY, CYLINDER HEAD COVER
12	2	424802	PINBOLT	STUD
13	2	421825	PINBOLT	STUD
14	2	421826	PIN	PIN
15	4	421828	BOLT	BOLT, CYLINDER HEAD
16	1	418494	TÆNDRØR	SPARK PLUGS
17	1	424803	TOPSTYKKE	HEAD SUBASSEMBLY, CYLINDER



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424804	KRUMTAPHUS	CRANKCASE SUBASSEMBLY.
2	1	424805	PAKDÅSE	SEAL, OIL
3	1	421832	OLIE SENSOR	SENSOR, ENGINE OIL
4	1	424806	TANKBESLAG	FRAME? FUEL TANK INSTALLTION
5	1	424807	GUMMIPROP	PLUG, RUBBER
6	1	421688	BESKYTTER OLIE	PROTECTOR, OIL
7	1	418547	BOLT	BOLT
8	2	421836	SKIVE	WASHER
9	2	421835	BUNDPROP	BOLT, DRAIN PLUG
10	1	418535	KLIPS	CLIPS
11	1	421905	ARM	ARM, GOVERNOR
12	1	421906	PAKDÅSE	SEAL, OIL
13	1	418416	LÅS	PIN
14	4	421838	BOLT	BOLT
17	2	418582	BOLT	BOLT
18	1	421904	SKIVE	WASHER? FLAT
19	1	424808	LEJE	BEARING




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424809	BUNDKAR	COVER, CRANKCASE
2	1	421846	PAKNING	GASKET, CRANKCASE
3	1	424810	OLIEPIND	PLUG SUBASSEMBLY, ENGINE OIL
4	1	424810	OLIEPIND	PLUG SUBASSEMBLY, ENGINE OIL
6	2	418418	PIN	PIN
7	7	421848	BOLT	BOLT
8	1	424811	LEJE	BEARING
9	1	421849	GEAR	GEAR ASSY, GOVERNOR
18	1	424805	PAKDÅSE	SEAL, OIL
19	1	424808	LEJE	BEARING




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424812	KRANKAKSEL	CRANKSHAFT ASSY.
4	1	424813	BALANCE AKSEL	SHAFT ASSY, BALANCING






POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424814	OLIESKRABERING	RING SET, OIL
2	2	421854	LÅSERING	CLIP, PISTON PIN
3	1	424815	STEMPEL	PISTON
4	1	421856	KRYDSPIND	PIN, PISTON
5	1	424816	PEJLSTANG	ROD, CONNECTING
7	1	424817	STEMPELRING I	RING, THE FIRST
8	1	424818	STEMPELRING II	RING, THE SECOND



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424819	KNASTAKSEL	CAMSHAFT ASSY.
3	1	424820	UDSTØDNINGSVENTIL	VALVE, EXHAUST
4	1	424821	INDSUGNINGSVENTIL	VALVE, INTAKE
5	1	421863	SÆDE	SEAT, VALVE SPRING
6	1	421864	SÆDE	RETAINER? EXHAUST VALVE
7	1	421865	ROTATOR VENTIL	ROTATOR, VALVE
8	1	421866	SÆDE	GUIDE, SEAL
9	2	421867	VENTIL	TAPPET, VALVE
10	2	421868	STØDSTANG	LIFTER SUBASSEMBLY, VALVE
11	1	421869	VENTILSTYR	PLATE SUBASSEMBLY, LIFTER STOPPER
12	2	418440	PINBOLT	PIN BOLT
13	2	421870	VIPPEARM	ROCKER, VALVE
14	2	418435	JUSTERINGSMØTRIK	ADJUSTMENT NUT
15	2	418434	MØTRIK	NUT
16	2	421871	MØTRIK	SPRING, VALVE
17	1	421872	VENTILDÆKSEL	RETAINER, VALVE SPRING




1

2

2


2

POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424822	REKYLSTARTER	STARTER ASSY, RECOIL
2	4	418576	BOLT	BOLT




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424823	BLÆSEHUS	SHROUD
2	1	424824	BESLAG	SHROUD, CYLINDER BODY
3	1	418581	BOLT	BOLT
4	5	418547	BOLT	BOLT
5	1	424825	KLIPS	CLIP






POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424826	KARBURATOR	CARBURETOR ASSY.
2	1	424827	PAKNING	GASKET, AIR CLEANER
3	1	424828	PAKNING	GASKET, CARBURETOR
33	1	424829	INSULATOR	PLATE, CARBURETOR INSULATOR
34	1	421880	PAKNING	GASKET, INLET

9



2




1


1



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	2	418448	MØTRIK	NUT
2	1	424830	LUFTFILTER	CLEANER, AIR
9	1	421840	BOLT	BOLT




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424831	UDSTØDNING	MUFFLER ASSY.
2	1	421888	PAKNING	GASKET, EXHAUST OUTLET
3	1	424832	UDSTØDNINGSRØR	PIPE, EXHAUST
4	1	424833	UDSTØDNINGSPAKNING	GASKET, MUFFLER
5	5	424834	MØTRIK	NUT




POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424835	BRÆNDSTOFTANK	TANK, FUEL
2	1	418592	FILTER	FILTER
3	1	424836	TANKDÆKSEL	COVER, FUEL TANK
4	1	418594	TANKSTUDS	NOZZLE PIPE
5	2	418595	KLEMME	CLAMP
6	1	421891	BRÆNDSTOFSLANGE	TUBE, FUEL
8	2	424834	MØTRIK	NUT






POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	421892	MØTRIK	NUT, FLYWHEEL
2	1	421893	STARTTRISSE	PULLEY, STARTER
3	1	421894	BLÆSEHJUL	IMPELLER
4	1	424837	SVINGHJUL	FLYWHEEL SUBASSEMBLY
5	1	418581	BOLT	BOLT
6	1	424838	TÆNDRØRSHÆTTE	CAP, SPARK PLUG
7	1	424839	STATOR	COIL SUBASSEMBLY, CHARGE
8	2	424840	BOLT	BOLT
9	1	424841	TÆNDSPOLE	COIL, IGNITION
12	1	424842	LEDNING	WIRE, IGNITION COIL STOP ENGINE
14	2	421896	BOLT	BOLT



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424843	GASREGULERING	CONTROL ASSY, THROTTLE
12	2	418547	BOLT	BOLT
13	1	421902	FJEDER	SPRING, THROTTLE VALVE RETURNING
14	1	421903	STANG	ROD, GOVERNEOR
15	1	421908	GASARM	SUPPORT SUBASSEMBLY, GOVERNOR
16	1	418448	MØTRIK	NUT
17	1	418488	BOLT TIL ARM	BOLT
18	1	421907	FJEDER	SPRING, GOVERNOR



POS	QTY	PARTNUMBER	BESKRIVELSE	DESCRIPTION
1	1	424844	STARTKONTAKT	MOTOR ASSY,STARTING
2	2	421875	BOLT	BOLT
3	1	424845	STARTRELÆ	RELAY, STARTING
4	2	424846	BOLT	BOLT
5	1	424847	LEDNING	WIRES, MOTOR