1845

1989

REPAIR PARTS MANUAL 18 H.P. LAWN TRACTOR With 45" Mower Deck MODEL 3583-5400

ONE YEAR LIMITED WARRANTY

For one (1) year from date of purchase by the first consumer for residential use (thirty (30) days commercial use), NOMA Outdoor Products Incorporated warrants that it will replace free of charge, including labor, any original part of any NOMA Outdoor Products Incorporated product found to be defective by any authorized Service Dealer or the factory, except the battery which is warranted for ninety (90) days from date of purchase.

This warranty does not cover engine, transmission, transaxle or differential (these items are covered by their manufacturer's own warranty). This warranty does not cover parts that have failed due to normal wear or parts that have failed subject to misuse or abuse. Transportation of the unit or part to and from an authorized Service Dealer or factory is the responsibility of the owner.

A step by step explanation as to what procedure should be followed for this Warranty is:

- If a part becomes defective, contact the store where the unit was purchased for the name and address of the authorized Service Dealer nearest to you.
- If you cannot locate an authorized Service Dealer, write Service Department of NOMA Outdoor Products Incorporated for the name and address of the authorized Service Dealer in your area or call the Service Department at 1-901-422-1690.
- Return the defective product, along with proof of purchase to such authorized Service Dealer for replacement of any defective part where covered by this warranty.

There is no other express warranty. Implied warranties, including those of merchantability and fitness for a particular purpose are limited to one (1) year from date of purchase. Liability for incidental or consequential damages are excluded.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

NOMA Outdoor Products Incorporated

Caller 8000

Jackson, TN 38308-8000

· UNIT PARTS AND SERVICE ·

This manual contains instructions for safety, assembly and maintenance. Read this manual carefully and completely so that you will know proper assembly, use and care of your unit. Also fill in and mail the registration card packed with the unit. For service other than covered in this manual, contact an authorized service dealer. A nationwide parts and service organization has been established to provide locally available parts and service. A list of authorized parts distributors has been included in this manual. When ordering repair parts, always give the following information: 1. The Part Name; 2. The Part Number; 3. The Quantity desired; 4. The Full (eight digit) Model Number of the unit. The model number will be found on a plate attached to the unit.




Look for this symbol. It means - ATTENTION! BECOME ALERT! A HAZARD TO OPERATOR, BYSTANDER, PROPERTY OR EQUIPMENT MAY EXIST.

NOMA Outdoor Products Incorporated Caller 8000 Jackson, TN 38308-8000

Part No. 309328

2589



45" Lawn Tractor Model 3583-5400
Always give the following information when ordering repair parts:

- 1. The PART NUMBER;
- 2. The PART NAME:
- 3. The QUANTITY DESIRED;
- 4. The MODEL NUMBER (As shown on Model Plate).

Send your part orders per the instructions on the front page.

To tell if a part is the left or right handed one, stand behind your mower.

Do not use the key numbers when ordering repair parts, always use the part numbers.


All replacement parts will be supplied in current production colors or in a neutral color.

A handling fee is applicable to small parts orders.

Key No.	Part No.	Description
1	1500	Locknut, 1/2-13 Thd.
2	122207	* Screw, Hex Hd 3/8-16 x 3 In.
3	302865	Ball Joint Assembly
4	46692	Nut, Hex Jam 3/8-24 Thd.
5	302864	Drag Link Assembly
6	57158	Ball Joint
7	36625	"E" Ring
8	52407	Bearing, Front Spindle
9	303200	Front Axle Assembly
10	53373	Cover, Axle End
11	642	Flatwasher
12	40394	Hub Cap
13	49562	Bearing
14	24167	Valve Stem
15	49401	Wheel, Front
16 17	57914 120369	Tire, Front
		* Nut, Hex 3/8-24 Thd.
18 19	120382 9781	* Lockwasher, Split 3/8-In. Front Spindle Assembly, L.H.
20	300327	Tie Rod Assembly
21	9180	Front Spindle Asembly, R.H.
22	58246	Bolt, Front Axle Pivot
23	706	Zerk, Grease 1/4-28 Thd
24	2483	Spring Washer
25	1499	Locknut, 3/8-16 Thd.
26	301251	Steering Wheel
27	456378	Roll Pin, 1/4-2 In.
28	272123	Nut, Jam 7/16-20
29	58243	Shaft, Steering Wheel
	ı	
]	
		1
ŀ		
	1	
Į		
l		
	İ	i
ł	1	
1		1
- 1	1	
ļ		i
Ì		


V	Kov I				
Key No.	Part No.	Description			
	<u> </u>				
30	58244				
31	301410	1			
32	58274				
33	22265	i e			
34	301398	1			
35	21682				
36	58289	Sector Gear			
37	52406	Eccentric, Steering Adjust			
38 39	180177				
	1498	Locknut, Hex 5/16-18 Thd.			
40	50947	Screw, Wa Hex 3/8-16 x 1-1/4 In.			
41	57563	Bracket, Stabilizer			
42	122017	Screw, Hex Hd 5/16-18 x 1 In.			
43 44	35498	Screw, Wa Hex Hd 5/16-18 x 3/4 In.			
45	120638 Transaxle	Washer, .328 x .60 x .11			
46	20507	^ Peerless, Model 801 Bolt, 5/16-18			
47	57217	Bracket, Brake Rod			
48	271184	Nut, Hex Keps 5/16-18			
49	45602	Washer, Flat .333 x .87 x .119			
50	57744	Spacer, 3/4 x 1-1/4 x 1-41/64 in.			
51	55893	Tire, Rear			
52	12459	Wheel Assembly, Rear			
53	22053	Retaining Ring			
54	180089	Screw, Hex Hd Cap 5/16-18 x 2-3/4 In.			
55	39628	Square Key			
56	120393	Washer			
57	180089	Screw, Hex Hd Cap 5/16-18 x 2-3/4 In.			
-	.0000	ου, οι, τιολικό σαρ ο, το το λ 2 ο, 4 μι.			
1					
		•			
1					
ł					
- 1	į				
- 1					
l					
1		(*) Standard hardware items - may be			
		purchased locally.			
İ		(^) Contact Tecumseh/Peerless author-			
ļ		ized service dealer for parts and			
		warranty.			

Part No. 309328




Repair Parts 45" Lawn Tractor Model 3583-5400

			Key	T	
No.	Part No.	Description	No.	Part No.	Description
1	307661	Seat	46	300194	Boot, Ignition Switch
2	995346	* Screw, Taptite 1/4-20 x 1/2 In.	47	300425	Choke Control 300 432
3	58221	Mounting Bracket, Seat	48	300175	Dash, Plastic Cover
4	20507	Shoulder Bolt	49	180022	* Screw, Hex Hd 1/4-20 x 1 In.
5	300634	Belt Guide	50	120228	* Screw, Hex Hd 5/16-18 x 5/8 ln.
6	300302	Screw, Taptite #10-24 x 1/2 In.	51	307332	Seat Bracket, Support L.H.
7	301542	Screw, Hex Hd #10-24 x 1 In.	52	120393	* Flatwasher, 11/32 In.
8	56676	Shoulder Bolt	53	120638	* Lockwasher, Split 5/16 In.
9	271166	Nut, Keps #10-24 THd.	54	122007	* Screw, Hex Hd 5/16-18 x 3/4 In.
10	301425	Support, Hood	55	1498	Locknut, 5/16-18 Thd.
11	307035	Hood	56	300844	Belt Guide
12	301540	Reflector, Headlight, R.H.	57	995346	Screw, Hex Hd 1/4-20 x 1/2 ln.
13	302333	Lens, Headlight	58	180020	* Screw, Hex Hd 1/4-20 3/4 In.
14	57796	Screw, Plastite #6 x 1/2 In.	59	307335	Fender Assembly
15	301541	Reflector, Headlight, L.H.	60	55021	Edging Fender
16	57478	Spring, Hood	61	53205	Cover, Spring
17	303037	Hood, Lower	62	305604	Pad, Hood Foam
18 19	301971 9792	Decal, Heat Reflector	63	307339	Bracket, Fender
20	120238	Lever, Mower Drive Control Jam Nut, 1/2-13 Thd.	64 65	305770	Decal, Caution
21	304438	Knob		58277	Switch
22	305598	Heat Shield	66 67	49335	Spring, Seat
23	300303	Screw, Plastite 1/4-20 x 3/4 In.	68	53744	Clip, Seat
24	9129	Bracket, Retaining	69	305602 305603	Pad, Hood Foam Pad, Hood Foam
25	120368	Flatwasher, 1/4 In.	70	305387	Bracket, Seat Stop
26	1288	Bracket, Cable Retainer	71	307374	Console
27	39298	Pulley	72	2968	Spacer, Flatwasher
28	57322	Shoulder Bolt	73	20864	Retaining Ring
29	300304	Cap, Fuel Tank	74	57196	Rod, Clutch Pedal
30	44811	Screw, Taptite 1/4-20 x 3/4 In.	75	12382	Foot Pad, R.H.
31	303043	Fuel Tank, 2 Gal.	76	57847	Spring, Return
32	41008	Clamp, Fuel Line	77	48160	Pad, Clutch/Brake
33	47452	Tubing, Fuel Line	78	68903	Decal, Parking Brake
34	9197	Brace, Dash	79	300308	Brake Pedal Assembly
35	1502	Locknut, 1/4-20 Thd.	80	307336	Main Frame
36	9132	Dash, Metal	81	120382	Flatwasher, 5/16 In.
37	9744	Bracket, Fuel Tank	82	55273	Nut, Hex 5/16-18 Thd.
38	9208	Brace, Dash & Fuel Tank	83	12381	Foot Pad, L.H.
39	300510	Throttle Control	84	9784	Bracket, Grille, R.H.
40	120622	Nut, Hex #8-32 Thd.	85	9785	Bracket, Grille, L.H.
41 42	300508 159585	Knob, Throttle Control Screw, Pan Hd #8-32 x 3/8 In.	86	56030 56361	Screw, Hex Hd 5/16-18 x 3/4 In.
43	159943	Screw, Pan Hd #8-32 x 3/8 in. Screw, Pan Hd #10-24 x 5/8 in.	87 88	56361 52077	Bracket, Axle Support Exhaust Tube
44	302049	Decal, Dash L.H.	89	35287	Screw, #8-32 x .62
45	300445	Decal, Dash R.H.	"	00207	33.311, #0 0L A .0L
~	000440	200ai, 243ii i i.i i.			
l					
		1	1 1	Ī	•
1		İ			
1		1			
		į			
- 1				Į	
-	1	,		1	
1				-	1
				1	
]				(*) Standard hardware items - may be
	1	İ	1 1	ŀ	purchased locally.
1	200000			<u></u>	pulchaseu locally.
art No. 3	41 1674732				7




No. Part No. Description		Lawn Tractor Model 3583-5400			
2 35258 Screw, Taptite #10-24 x 3/8 ln. 3 57444 Wire Tie 4 47828 Cap, Oil Drain Tube 5 52404 Tube, Oil Drain 6 Engine See Footnote Below 7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 ln. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 ln. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 ln. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 ln. 1dler Arm 19 1303031 Pulley, Idler	Key No.	Part No.	Description		
3 57444 Wire Tie 4 47828 Cap, Oil Drain Tube 5 52404 Tube, Oil Drain 6 Engine See Footnote Below 7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler		1	Clip, Cable		
4 47828 Cap, Oil Drain Tube 5 52404 Tube, Oil Drain 6 Engine See Footnote Below 7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler		\$			
5 52404 Tube, Oil Drain 6 Engine ~ See Footnote Below 7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler		•			
6 Engine ~ See Footnote Below 7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler					
7 58356 Guide Belt/Drag Link 8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler		•			
8 304438 Knob 9 120238 Jam Nut 1/2-13 Hex 10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler					
10 302717 Shift Lever 11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler					
11 302245 Shift Tube 12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 1dler Arm Bulkhead 24 303031 Pulley, Idler		120238	Jam Nut 1/2-13 Hex		
12 1498 Locknut, Hex 5/16-18 Thd. 13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 10 Idler Arm 23 9240 24 303031 Pulley, Idler			1		
13 57220 Scrw, Pan Hd 14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler		J.			
14 300634 Belt Guide 15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler					
15 302716 Assembly, Shift Bracket 16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler					
16 45602 Washer, 5/16 In. 17 56255 Screw, Hex Hd Nylon .14-28 x 3/4 In. 18 50947 Screw, Taptite 3/8-16 x 1-1/4 In. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler					
18 50947 Screw, Taptite 3/8-16 x 1-1/4 ln. 19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 ln. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler					
19 138489 Starwasher 20 57204 Rod, Clutch 21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler	17		Screw, Hex Hd Nylon .14-28 x 3/4 In.		
20					
21 45892 Carriage Bolt 3/8-16 x 1-1/2 In. 22 300154 Idler Arm 23 9240 Bulkhead 24 303031 Pulley, Idler			1		
22 300154 Idler Arm					
23 9240 Bulkhead 24 303031 Pulley, Idler					
24 303031 Pulley, Idler					
	25	39659			
	1 1				
	1 1				
	1 1				
]				
	1 1				
			·		
]				
	1				

Key No.	Part No.	Description
26	57476	Switch
27	1499	Locknut, 3/8-16 Thd.
28	300793	Shoulder Bolt
29	57203	Brake Rod
30	56359	Spring, Clutch
31 32	120229	* Screw, Hex Hd 5/16-18 x 5/8 lp. Belt Guide
33	300440 120228	Screw, Hex Hd 5/16-18 x 5/8 ln.
34	48148	Screw, Taptite 3/8-16 x 1 In.
35	307337	Hitch Frame
36	57157	Washer, Special
37	137185	Cotter Pin
38	54873	Trough, Oil Drain
39	56538	Wire Retainer
40	305637	Pulley, Engine
41 42	57555 304246	Key, 1/4 x 1/4 x 1-1/2 In. Spacer, Engine Pulley
43	22053	Ring, Retaining
44	3021	Key, Woodruff
45	54692	Pulley, Input
46	56431	Washer, Pilot
47	57556	V-Belt
48	215668	Screw, Hex Hd 7/16-20 x 3/4 ln.
49 50	120383	* Lockwasher, Split 7/16 In.
30	180079	Screw, Hex Hd 5/16-18 x 2-1/4 In.
- 1]	· ·
I		
ı		
- 1	ŀ	
1	1	
	l	
1		
1	l	
	.	
- 1	l	
		,
ł		
1		
- 1		
1		
ļ		
	1	
1	1	
	lo	*) Standard hardware items - may be
	[purchased locally.




Key		Tractor Model 3303-3400	-	<u> </u>	1	
No.	Part No.	Description		Key No.	Part No.	Description
1	58329	Hand Grip, Height Adjust Lever		26	9186	Link Assembly, Right Slde
2	58325	Knob, Height Adjust Lever		27	57744	Spacer
3	58326	Spring, Height Adjust Lever		28	307334	Brace, Height Adjust Lever Support
5	301897 300339	Decal, Height Adjust	1	29	58333	Bracket, Heigth Adjust Lever Support
6	300339	Cover, Height Adjust Lever Screw, #10 x 1/2 In.		30	39298 9149	Pulley Bracket, Retainer
7	301538	Screw, #10 x 1 In.		32	58336	Shoulder Bolt
8	58330	Actuator Rod, Height Adjust Lever		33	8260	Hair Pin Cotter
9	9143	Lever Height Adjust		34	9239	Clevis
10	35287	Screw, Hex Wa Hd #8-32 x 3/4 In.		35	120373	Nut, Square 5/16-18 Thd.
11	9435	Pointer, Height Adjust Lever	1	36	300317	Pin, Clevis
12 13	138479 300311	Lockwasher, Ext. Lock "E" Ring		37 38	302213	Cable, Deck Lift
14	44108	Wide Flange Locknut, 5/16-18 Thd.		39	120613 126211	* Nut, Hex 1/4-28 Thd. * Carriage Bolt, 5/16-18 x 5/8 In.
15	1498	Locknut, Hex 5/16-18 Thd.	1	40	301440	Cable Assembly, Blade Engage
16	300310	Pin, Clevis		41	120396	* Flatwasher 17/32 In.
17	35498	Screw, Taptite 5/16-18 x 3/4 In.		42	58247	Nut, Adjusting
18	300171	Shoulder Bolt		43	9117	Bracket, Rear Hanger
19	439455	Screw, Pan Hd 5/16-18 x 9/16 In.		44	9569	Rear Lift Assembly
20	9643	Washer, Curved 11/32 In.	l	45	120375	* Nut, Hex 1/4-20 Thd.
21 22	180077 301239	* Screw, Hex Hd 5/16-18 x 3/4 In. Pawl Assembly	1	46 47	39522	Clevis Pin * Nut, Square 1/4-20 Thd.
23	301239	Quadrant Assembly		48	120372 121222	* Pin, Cotter 3/32 x 3/4 In.
24	180079	* Screw, Hex Hd 5/16-18 x 1 In.		49	9405	Rear Clevis, Lift Cable
25	1502	Locknut, Hex 1/4-20 Thd.				riou. Giorio, ain Guolo
1 1						
1 1						,
i i						
	l					
1 1						
i i	İ					
1 1						
1 1	1					
1 1	1					
	-					
	Ī					•
						İ
	I]		
	Į			l		
	1					
				1		
		•	ı	l		(*) Standard hardware items - may be
						purchased locally.



45"	Lawn	ractor Model 3583-5400			
Key No.	Part No.	Description	Key No.	Part No.	Description
No. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41	Part No. 57818 300473 9401 180077 300179 300180 44108 120393 306973 41601 996416 1498 35410 1499 271172 300491 1346 121954 303030 57325 122017 58247 58306 301091 8260 58315 35214 40886 1502 300238 303247 300315 135624 1343 300215 303029 41890 4107 45892 120834 57318	Chute Guard Spring Tension Extension, Idler Arm Screw, Hex Hd 5/16-18 x 3/4 In. Bracket, Idler Shoulder Bolt Nut, Hex Wide Flange 5/16-18 Thd. Flatwasher 11/32 In. Brake Pad Revet, Brake Pad Flatwasher 3/8 In. Locknut 5/16-18 Thd. Spring Locknut, 3/8-16 Thd. Keps Nut, 1/4-20 Thd. Idler Arm Assembly (Incl Nos. 9 & 10) Retainer, Belt Screw, Hex Hd 1/4-20 x 2 In. Pulley, Idler Carriage Bolt, 3/8-16 x 2 in. Screw, Hex Hd 5/16-18 x 1 In. Nut, Adjusting Rod, Deck Hitch Bracket, Deck Front Hairpin Cotter Lift Support Plate Flatwasher, 21/64 In. Screw, Taptite 1/4-20 Thd. Locknut, 1/4-20 Thd. Belt Guard Blade Brake Assembly (Incl. Nos. 9 & 33) Rod, Brake Release Rivet, Brake Pad Idler Arm Spring Pulley, Idler Shoulder Bolt Flatwasher Shoulder Bolt Flatwasher Shoulder Bolt Screw, Hex Hd 5/16-18 x 1/2 In. Retainer, Belt		Part No. 300103 58250 55767 57317 57360 271184 57314 126211 23763 52584 300102 39573 2483 56821 300345 45171 56424 1282 56365 56390 51449 49562 50818 55547 50616 56425 120228 304076 120377 304077 120382 58128 58164 58165 300142 58125 50634 300294 58162 58122	Bracket, Wheel Mou Bracket, Lift R.H. Spring, Discharge C Rod, Pivot Bracket, Pivot * Nut, Keps 5/16-18 T Skid Bar * Carriage Bolt, 5/16-Wheel Axie Wheel, Deck Bracket, Wheel Mou Screw, Hex Hd 3/8-2 Formed Washer Blade 36" * Screw, Hex Hd 5/16 Wide Flange Locknu Quill Assembly Locknut, Flange Flatwasher Pulley Spacer Bearing Spacer, Tube Quill Dust Shield Saddle & Shaft Asse * Screw, Hex Hd 5/16- Quill Assembly Locknut 3/8-16 Pulley Lockwasher, Split 3/4 Spacer, Tube Quill Saddle & Shaft Asse V-Belt Quill Assembly Screw, Hex Hd 5/16- Pulley Half Quill Screw, Hex Hd 5/16- Pulley Half
35 36 37 38 39 40	300215 303029 41890 4107 45892 120834	Spring Pulley, Idler Shoulder Bolt Flatwasher Shoulder Bolt * Screw, Hex Hd 5/16-18 x 1/2 In.	80 81 82 83 84	300142 58125 50634 300294 58162	V-Belt Quill Assembly Screw, Hex Hd 5/16- Pulley Half
 Part No. 5	200220	·			(*) Standard hardwarepurchased locally.

Key No.	Part No.	Description
46	300103	Bracket, Wheel Mount, L. H.
47	58250	Bracket, Lift R.H.
48 49	55767	Spring, Discharge Chute Rod, Pivot
50	57317 57360	Bracket, Pivot
51	271184	* Nut, Keps 5/16-18 Thd.
52	57314	Skid Bar
53	126211	* Carriage Bolt, 5/16-18 Thd.
54	23763	Wheel Axie
55	52584	Wheel, Deck
56 57	300102	Bracket, Wheel Mount R.H.
57 58	39573 2483	Screw, Hex Hd 3/8-24 x 1 In. Formed Washer
59	56821	Blade 36"
60	300345	* Screw, Hex Hd 5/16-18 x 1-3/8 In.
61	45171	Wide Flange Locknut 5/16-18 Thd.
62	56424	Quill Assembly
63	1282	Locknut, Flange
64	56365	Flatwasher
65 66	56390 51449	Pulley
67	49562	Spacer Bearing
68	50818	Spacer, Tube
69	55547	Quill
70	50616	Dust Shield
71	56425	Saddle & Shaft Assembly
72	120228	* Screw, Hex Hd 5/16-18 x 5/8 ln.
73 74	304076 120377	Quill Assembly Locknut 3/8-16
75	304077	Pulley
76	120382	Lockwasher, Split 3/8
77	58128	Spacer, Tube
78	58164	Quill
79	58165	Saddle & Shaft Assembly
80	300142	V-Belt
81 82	58125 50634	Quill Assembly
83	300294	Screw, Hex Hd 5/16-18 x 7/8 ln. Pulley Half
84	58162	Quill
85	58122	Saddle & Shaft Assembly
		-
- 1		
1		
į		
1		
		ľ
- 1		
1		
- 1		
		(*) Standard hardware items - may be
- 1		numbered leading



Key No.	Part No.	Description
1	57547	Switch, Seat
2 3	302257	Battery
3	120854	Screw, Hex Hd 1/4-20 x 5/8 ln.
4	57552	Rod, Battery Top
5	120375	Nut, Reg Hex 1/4-20
6	120380	Washer, Split .263 x .49 x .07 ln.
7	120392	Washer, Flat .281 x .63 x .065 ln.
8	300626	Key, Ignition
9	271172	Nut, Hex Keps 1/2-20
10	58277	Switch
11	271184	Nut, Hex Keps 5/16-18
12	57551	Rod, Battery
13	122017	Screw, 5/16-18 x 1 In.
14	1498	Locknut, Reg Hex 5/16-18
15	138538	Washer, Reg .32 x .61 x .02 in.
16	55511	Ground Wire
17	300193	Nut 5/18-32
18	300295	Switch

Key No.	Part No.	Description	
140.	Part No.	Description	
19	300362	Wire Harness	
20	300334	Light Switch	
21	57769	Bulb, Indicator	
22	300965	Light Harness	
23	300220	Safety, Switch	
24	302031	Fuse	
25	120368	Nut, Reg Hex 5/16-24	
26	138485	Washer, .320 x .61 x .03	
27	1502	Nut, Reg Hex 1/4-2	
28	187745	Screw 1/4-20 x 3/4 ln.	
29	53716	Solenoid	
30	57476	Switch	
31	303064	Assembly, Light Wire	
32	52572	Bulb, Headlight	
33	41482	Clip, Press Wire	
34	54888	Retainer, Wire	
35	305511	Connector	
36	305431	Wire Assembly, Pigtail Seat Switch	